



**PLEASE BE ADVISED THAT  
THIS REEL HAS BEEN TESTED  
AND PRE WOUND AT THE FACTORY.**

**INSTALLATION PROCEDURE**

- 1. CAREFULLY REMOVE REEL FROM SKID, HANG REEL AS SHOWN ON PLANS OR ATTACHED INSTALLATION SHEET.**
- 2. ATTACH 4' X 6" TUBING FROM EXHAUST SIDE OF REEL TO 6" O.D. STUB OFF OF DUCT WORK WITH CLAMPS PROVIDED.**
- 3. ATTACH EXHAUST HOSE TO HOUSING MOUNTED TO HOSE REEL WITH CLAMP PROVIDED.**
- 4. REMOVE 1/4" TIE-ROD FROM REEL AND DISPOSE OF.**
- 5. PULL ON HOSE TO RELEASE LATCH ON REEL AND SLOWLY WIND HOSE ON TO REEL.**
- 6. STOP COLLAR SHOULD BE REPOSITIONED ON THE EXHAUST HOSE AS REQUIRED BY THE END USER.**

**NOTE**

**DO NOT REMOVE TIE-ROD (STEP #4) UNTIL STEPS 1 THROUGH 3 ARE COMPLETED.**

**REELS MUST BE HUNG LEVEL AND HOISTED INTO PLACE LEVEL TO PREVENT RACKING, WHICH MAY CAUSE BINDING IN THE OPERATION OF THE REEL.**